

July, 3rd 2008

## Paper Calibration Recommended Values

### Brand / Type

Kodak :	D-Max			Cal. Fac		
	D-Max Red	D-max Green	D-max Blue	Red	Green	Blue
KodakPortra Endura	2,33	2,14	2,01	1,00	0,96	0,93
Supra Endura	2,44	2,24	2,12	1,00	0,96	0,93
Endura Metallic	2,47	2,15	2,08	1,00	0,99	0,94
Ultra Endura	2,52	2,23	2,13	1,04	0,98	0,94
Royal/Edge Generations	2,13	1,97	1,81	1,06	0,97	0,97

### Fuji :

FujiSuper Type	2,45	2,35	2,30	1,00	1,00	0,98
Fuji CA new	2,10	2,10	2,00	1,03	1,00	0,98
Fuji DP II	2,30	2,30	2,20	1,03	1,00	0,98
Crystal Archive	2,20	2,25	2,15	1,00	1,00	0,98

### Mitsubishi :

MitsubishiSA H	2,30	2,20	2,05	1,03	1,00	0,98
MitsubishiNew	2,15	2,20	2,10	1,02	1,01	0,98

### Please note:

All values are based on fresh chemicals. By adjusting the Cal. Factors you will be able to optimise the PBL.